

Error de Método

Ing. Pablo De Césare
2025

Error de Método

- Se caracterizan porque el sistema de medición altera el sistema a medir.
 - Absorción de energía.
 - Desadaptación impedancias.

Error de Método

Nomenclatura

X_i : valor indicado de la magnitud a medir

\bar{X} : valor más probable o “valor verdadero”

El error absoluto de la medición

$$\Delta X_i = X_i - \bar{X}$$


Error relativo

$$e_i = \Delta X_i / X_i \quad \text{ó} \quad e_i\% = \Delta X_i / X_i$$


$$e_i = \frac{X_i - \bar{X}}{\bar{X}} = \longrightarrow \boxed{\bar{X} = \frac{X_i}{1 + e_i}}$$

Error de Método

1° analizaremos el caso de medir la tensión de salida de un dipolo activo




Error de Método



El dipolo activo se puede reducir a fuente V_{th} con una R_{th}


Error de Método



Con L abierta : $V = V_{th}$

Con L cerrada : ??


Error de Método



Con la llave cerrada la tensión indicada por el voltímetro V_i es distinta V_{th}

$$V = V_{th}$$

Al cerrar la llave



$$V_i = \frac{V}{R_{th} + R_v} \cdot R_v$$

$$V_i = \frac{V}{1 + \frac{R_{th}}{R_v}}$$

$$R_v$$

Error de Método

$$V_i = \frac{V}{1 + \frac{R_{th}}{R_v}}$$

$$V_i = V_{th} \quad \text{cuando}$$

$$R_{th} = 0$$

$$R_v = \infty$$


Calculo del error de método

$$\Delta V_i = V_i - V$$

reemplazamos a expresión de V_i

$$\Delta V_i = \frac{V}{1 + \frac{R_{th}}{R_v}} - V$$

$$e_m = \Delta V_i / V$$




$$e_m = \frac{1}{1 + \frac{R_{th}}{R_v}} - 1$$

Error de Método

$$e_m = \frac{1}{1 + \frac{R_{th}}{R_v}} - 1$$

$$V = \frac{V_i}{1 + e_m}$$

Ya lo dicen las notas de aplicación



Loading Errors Due to Input Resistance – Measurement loading errors occur when the resistance of the DUT is an appreciable percentage of the multimeter's own input resistance. Figure 7 shows this error source.

To reduce the effects of loading errors, and to minimize noise pickup, set the Agilent 34401A's input resistance to greater than 10 G Ω for the 100 mVdc, 1 Vdc, and 10 Vdc ranges. The input resistance is maintained at 10 M Ω for the 100 Vdc and 1000 Vdc ranges.

Calibrador DMM

Pioneer/Instrumentation

CALIBRATOR MODEL 450A

PORTABLE PRECISION VOLTAGE SOURCE

- FOUR OUTPUT VOLTAGES ... 10 VDC, 1.0 VDC, 100mVDC, and 10mVDC
- $\pm 0.05\%$ ACCURACY ... 10 V, 1V, and 100mV OUTPUTS
- $\pm 0.1\%$ ACCURACY 10mV OUTPUT
- LOW OUTPUT RESISTANCE
- SHORT CIRCUIT PROOF OUTPUTS
- BATTERY POWERED
- PROVISION FOR EXTERNAL SUPPLY
- LED BATTERY CONDITION INDICATOR
- LOW COST



APPLICATIONS

- Calibration of Digital Voltmeters and Multimeters
- Calibration of VOM's
- DC Calibration of Oscilloscopes
- Portable Voltage Reference
- Calibration of Chart Recorders

Pioneer/Instrumentation
DIVISION OF PIONEER-STANDARD ELECTRONICS
4800 EAST 131ST STREET / CLEVELAND, OHIO
(216) 58

SPECIFICATIONS

Output Voltages: 10mVDC, 100mVDC, 1.0VDC, 10.0VDC

Output Resistance: 5 ohms typical for 10mVDC
50 ohms typical for 100mVDC
500 ohms typical for 1.0 VDC
1000 ohms typical for 10.0VDC

Note: Specific output resistance on each unit.

Guaranteed

Accuracy: $\pm 0.05\%$ (15 to 35°C) on 100 mV, 1 V, 10 V Outputs
 $\pm 0.1\%$ (15 to 35°C) on 10 mV Output

Temp. Coefficient: 10 PPM/°C typical 0 - 50°C

Output Stabilization Time: 30 seconds to rated accuracy.

Power Required: Self contained batteries (2 Mallory MN 1604 alkaline cells, 9 VDC, or equivalent) or external 15 to 20 VDC supply at approximately 15 MA

Battery Life: Minimum of 10 hours @ continuous duty
Approximately 6 months @ normal intermittent duty.

Weight: Approximately 16 ounces with batteries

Dimensions: 3 1/2" wide, 6" long, 2" deep

OPERATING INSTRUCTIONS

STANDARD AND INTERMEDIATE OUTPUTS:

In standard operation the desired output range is connected to the instrument to be calibrated. Intermediate output voltages are available by using combinations of the positive output terminals. In this mode of operation the resultant output voltage is a subtractive function of the lower from the higher value.

ACCURACY AND LOADING CONSIDERATIONS:

The Quik-E calibrator is designed to provide rated accuracy into high input resistance instruments such as digital panel meters and test equipment. When instruments of lower input resistance are calibrated, and where it is desirable to know the specific effect of loading on the Quik-E the following formula can be utilized.

$$E_a = \frac{R_{in}}{R_{in} + R_q} \times \text{rated output}$$

where: E_a = actual output
 R_{in} = load resistance
 R_q = Quik-E output resistance

EXAMPLE: In the case of an instrument of 20,000 ohms per volt sensitivity calibrated on the 10.0 VDC output of the Quik-E calibrator, the actual output voltage based on loading is 9.95 VDC.

$$E_a = \frac{20,000}{20,000 + 1,000} \times 10.0 = 9.95 \text{ VDC}$$

EXTERNAL SUPPLY OPERATION:

The Quik-E calibrator can be operated from an external bench supply or with the AC adapter when continuous operation or conservation of battery life is desirable.

The external supply of 15 to 20 VDC is connected to the "EXT PWR" jacks. This provides a continuous output from the Quik-E for use as a standard reference.

Protection is provided in the external supply input to protect the device from damage due to accidental polarity reversal of the supply.

BATTERY CONDITION INDICATOR:

A Light Emitting Diode is provided on the front panel to indicate the presence of sufficient battery voltage for accurate operation. The relative intensity of this LED is indicative of battery strength. As long as there is visible indication from this LED, regardless of the intensity, the Quik-E calibrator will operate within rated accuracy specifications.

REPRESENTATIVE

Ordering Information -- Specify

Model 450A Quik-E Calibrator . \$99.50

Model PS45A-AC Adapter Accessory for 110 VAC Line Operation. \$25.00

Statement of Calibration traceable to National Bureau of Standards . \$15.00

NORMAL MAINTENANCE CONSIDERATIONS:

Battery Replacement is accomplished by removing the 4 mounting screws on the cover plate and carefully removing the cover and foam material covering the battery cavity. The old batteries should be removed and discarded and replaced with two Mallory MN 1604 alkaline cells or their equivalent.

Periodic Calibration Checks are recommended for reliable operation. These should be performed on a 6 month interval. It is recommended that recalibration, when required, be performed by Pioneer/Instrumentation, or a qualified instrument laboratory, utilizing differential measurement techniques.

A Statement of Calibration traceable to the National Bureau of Standards can be provided allowing the Quik-E calibrator to be utilized as a secondary standard where portability and ruggedness are required.

The statement of calibration furnished lists the actual output values of the unit calibrated.

Que pasa en AC?

No inventamos nada tampoco

AC Loading Errors – In the ac voltage function, the input of the Agilent 34401A appears as a 1MW resistance in parallel with 100 pF of capacitance. The cabling used to connect signals to the multimeter will also add additional capacitance and loading. Figure 2 shows the multimeter's approximate input resistance at various frequencies.

| Input Frequency | Input Resistance |
|-----------------|------------------|
| 100 Hz | 1 MW |
| 1 kHz | 850 kW |
| 10 kHz | 160 kW |
| 100 kHz | 16 kW |

Figure 2.

For Low Frequencies:

$$\text{Error (\%)} = \frac{-100 \times R_s}{R_s + 1M\Omega}$$

Additional error for high frequencies:

Where:

$$\text{Error (\%)} = 100 \times \left[\frac{1}{\sqrt{1 + (2\pi \times F \times R_s \times C_{in})^2}} - 1 \right]$$

R_s = Source Resistance

F = Input Frequency

C_{in} = Input Capacitance
(100 pF) plus Cable Capacitance

Note: Be sure to use low-capacitance cable when measuring high-frequency signals.

Especificaciones de Impedancia de Entrada típicas

DC Voltage

Measurement Method:

Continuously integrating multi-slope III
A-D converter

A-D Linearity:

0.0002% of reading + 0.0001% of range

Input Resistance:

10 M Ω or 0.1 V, 1 V, 10 V ranges:

Selectable > 10,000 M Ω

100 V, 1000 V ranges: 10 M Ω \pm 1%

Input Bias Current: < 30 pA at 25°C

Input Protection: 1000 V all ranges

dcV:dcV ratio accuracy:

V_{input} Accuracy + $V_{\text{relevance}}$ Accuracy

True RMS AC Voltage

Measurement Method:

AC-coupled true rms-measures the ac
component of the input with up to 400 Vdc
of bias on any range.

Crest Factor:

Maximum of 5:1 at full scale.

Additional Crest Factor errors (non-sinewave):

Crest factor 1-2: 0.05% of reading

Crest factor 2-3: 0.15% of reading

Crest factor 3-4: 0.30% of reading

Crest factor 4-5: 0.40% of reading

Input Impedance:

1 M Ω \pm 2% in parallel with 100 pF

Input Protection: 750 Vrms all ranges

Model 187 & 189


Manual de Uso

Impedancia de entrada

| Función | Impedancia de entrada (Nominal) |
|-------------|---------------------------------|
| Voltios, mV | 10 M Ω , < 100 pF |




Un osciloscopio es peor!!!



| | |
|-------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Sensibilidad | 1 mV a 5 V/DIV , 12 pasos en secuencia 1-2-5 |
| Exactitud | 5mV a 5V/DIV $\leq 3\%$, 1 mV –2 mV/DIV $\leq 5\%$ (10°C a 35°C) |
| Sensibilidad del Vernier | A 1 / 2,5 o menos del valor indicado en el Panel |
| Ancho de Banda | 5 mV a 5 V/DIV DC a 50 MHz |
| | 1mV – 2 mV /DIV DC a 15 MHz |
| | Acoplado en AC , la frecuencia de corte inferior es 10 Hz (- 3 dB con referencia a 8 div a 100 KHz) |
| Rise Time | 5 mV – 5 V/DIV = 7 nS 1 mV – 2 mV/DIV = 23 nS |
| Impedancia de Entrada | 1 MOhm $\pm 2\%$ // Aprox. 25 pF |
| Características de respuesta para Onda Cuadrada | Sobreimpulso : $\leq 5\%$ (Sensibilidad en 10 mV/DIV) Otras distorsiones para otros rangos : agregar 5 % al valor indicado anteriormente (10 °C a 35 °C) |
| Desplazamiento del Balance de CC | 5 mV a 5 V/DIV : ± 0.5 DIV , 1 mV – 2mV/DIV : ± 2.0 DIV |
| Linealidad | $< \pm 0.1$ DIV de cambio de amplitud cuando una señal de 2 DIV de amplitud , centrada en la graticula , es movida verticalmente |

Es importante ver que la impedancia de entrada esta dada con un error de $\pm 2\%$.
Es de esperar que el error de método también tenga asociado un error

Error de método en ORC



$$V_i = \frac{\frac{R_0 * (\frac{-j}{\omega C_0})}{R_0 - j \frac{1}{\omega C_0}} V}{\frac{R_0 * (\frac{-j}{\omega C_0})}{R_0 - j \frac{1}{\omega C_0}} + R_t}$$

Sacando denominador común $R_0 - j \frac{1}{\omega C_0}$

$$V_i = \frac{R_0 * (\frac{-j}{\omega C_0})}{R_0 * (\frac{-j}{\omega C_0}) + R_t * (R_0 - j \frac{1}{\omega C_0})} V$$

$$T = \frac{V_i}{V}$$

$$T = \frac{-jR_0}{-jR_0 + R_t R_0 \omega C_0 - jR_t}$$

Multiplicando y dividiendo por $\frac{j}{R_0}$


$$T = \frac{1}{1 + jR_t \omega C_0 + \frac{R_t}{R_0}}$$

$$T = \frac{1}{\sqrt{(\frac{R_t}{R_0} + 1)^2 + (R_t \omega C_0)^2}}$$

El error de método es: $Em = \frac{\Delta V_i}{V} = \frac{V_i - V}{V} = \frac{V_i}{V} - \frac{V}{V} = T - 1$

$$Em = \frac{1}{\sqrt{(\frac{R_t}{R_0} + 1)^2 + (R_t \omega C_0)^2}} - 1$$

Transferencia de entrada





$$R_o = 1\text{M}\Omega$$

$$C_o = 22\text{ pF}$$

$$T = \frac{V_i}{V_v} = \frac{1}{\sqrt{\left(1 + \frac{R_t}{R_o}\right)^2 + (\omega^2 \cdot C_o^2 \cdot R_t^2)}}$$

Transferencia

Em



Error de Método

Vamos a analizar ahora el error que suelen cometer los voltímetros digitales que expresan la lectura en dBm

**Multímetros digitales de
RMS verdadero**

**TX-DMM™
TX1 y TX3**



Mediciones de voltaje de dB y dBm

| Medición | Tecla de menú | Conexión de cables | Pantalla principal | Pantalla superior |
|-----------------------------|-----------------------------------|--------------------|--------------------|-------------------|
| dB (sólo TX3) ¹ | dB o dBm (pulse para alternar) | | AC | dB |
| dBm (sólo TX3) ² | | | AC | dBm |

¹ Lectura dB = $20 \times \log (\text{lectura de la pantalla principal/ref})$, donde ref = 1 V es el valor predeterminado.

² Lectura dBm = $10 \times \log (\text{lectura de la pantalla principal}^2/R)$, donde R=600 Ω

Error de Método

$$P[dBm] = 10 \cdot \log \left(\frac{\frac{V^2}{R}}{1mW} \right)$$

$$1mW = \frac{V_{ref}^2}{600\Omega} \rightarrow V_{ref} = \sqrt{1mW \cdot 600\Omega} = 0.7746V$$

$$P[dBm] = 10 \cdot \log \left(\frac{\frac{V^2}{R}}{\frac{(0.7746V)^2}{600\Omega}} \right)$$

$$P[dBm] = 10 \cdot \log \left(\frac{\frac{V^2}{R}}{\frac{(0.7746V)^2}{600\Omega}} \right) = 20 \cdot \log \left(\frac{V}{0.7746} \right) + 10 \cdot \log \left(\frac{600\Omega}{R} \right)$$

Error de Método

$$P[dBm] = 20.\log\left(\frac{V}{0.7746}\right) + 10.\log\left(\frac{600\Omega}{R}\right)$$

Conversión que aplica el voltímetro para pasar de tensión a potencia en dBm

Error de método por ser distinta la impedancia sobre la cual se mide tensión

Con lo cual

$$P = P_i + \text{Corrección por Error de método}$$

Resumen

Error de Método

- La universalidad del problema!!
- ¿Siempre es necesario realizar la corrección por error de método?
 - Es necesario fijar un criterio:
 - Que sea 10 veces menor que el error de lectura.
- Siempre que se realice una medición interpretar de que manera los instrumentos afectan al sistema, utilizando para ello su CONOCIMIENTO METROLOGICO razonando cada punto del procedimiento de medición.